

RESET AE-300

Erste Serien ohne roten / rotbraunen Punkt im Batteriefach. Das Gerät muß zum Reset geöffnet werden, damit der SYS-Taster auf der CPU-Platine erreichbar ist.

5) Have just received AE-300 resetting (initialization) procedures which I translate as follows:

Pressing SYS key, turn POWER switch ON. (SYS key is on the CPU p.c. board.) Then, press as follows:

2nd>BAND key (BAND key is on the CPU p.c. board.) 1 should be displayed.

1>0>0>0>0>1>0>0>ENT

2 should be displayed.

0>0>0>0>0>ENT

MANUAL/PROG

1 should be displayed.

ENT>0>ENT>6>ENT>7>4>9> .>2>7>5>UP>DOWN

2>ENT>6>ENT>1>0>8>ENT>7>4>9> .>2>7>5>UP>DOWN

3>ENT>1>0>8>ENT>1>9>5>ENT>7>4>9> .>2>7>5>UP>DOWN

4>ENT>1>9>5>ENT>5>1>2>ENT>7>4>9> .>2>7>5>UP>DOWN

5>ENT>5>1>2>ENT>1>0>1>3>ENT>2>8>7> .>5>2>5>UP>UP

6>ENT>1>0>1>3>ENT>1>5>7>0>ENT>2>8>7> .>5>2>5>DOWN>UP

7>ENT>1>5>7>0>ENT>2>0>6>0>ENT>7>4>9> .>2>7>5>DOWN>DOWN>MANUAL

This completes resetting, so turn POWER off here. Again, turn on POWER, and attempt writing search program and memory channels.

example: Search Program

freq 850MHz - 900MHz, Bank 0, Mode FM, Step 12.5KHz

SEARCH>PROG>SEARCH>0>ENT>850>ENT>900>ENT>MODE>(FM)>ENT>STEP>(12.5)>ENT

Should you still find troubles, please let us know ASAP.

Best regards,

Entfällt bei der Version AE 300 Software reset v. Aufse
Siehe Resetanleitung AE 300 - S2 . PDF

AE 300 - S1. PDF