

How To Select The PC Software For Your AT-778UV



Power On: in power off state press , the LCD displays "WELCOME" then will displays current frequency or channel.

1. After you power on your two way mobile radio, if your radio's LCD displays as below (RDW), plz use firmware [AT_778UV_SetOSetup_2.00](#) and [AT_778UV_Setup_2.00](#) for programing the radio.



2. After you power on your two way mobile radio, if your radio's LCD displays as below (VOX), plz use firmware [AT_778UV\(VOX\)_SetOSetup_3.00](#) and [AT_778UV\(VOX\)_Setup_3.00](#) for programing the radio.



*If you use wrong firmware for programming, the radio will not work and show as below picture, but it is not broken. After load into correct firmware, it will work fine.

