



Transmit Frequency Modification Installation Instructions:

The following transmit frequency modification software works with SmartSDR™ for Windows

1. Ensure the proper installation and operation of your FLEX-6000 Signature Series SDR using SmartSDR for Windows before continuing.
2. Copy the enclosed "TURF" (*.turf) file to your Desktop.
3. Start SmartSDR for Windows and connect to your FLEX-6000.
4. In the SmartSDR menu bar, select "**Radio Setup**".
5. Click on the "**Radio**" tab.
6. Locate the radio's *Region* information line and click on the "**Change**" button.
7. When the file selection dialog box appears, select the TURF file sent to you for your radio and then click the "**Open**" button.
8. When the modification of the radio's transmit restriction is complete, a popup "bubble message" will be displayed indicating if the radio was modified successfully.